

## A collection of Bosch kitchen appliances and accessories. The central item is a large food processor with a black base and a clear plastic bowl. To its left is a smaller chopper with a grey base and a clear bowl. In front of the chopper is a small clear measuring cup. To the right of the food processor is a blender with a black base and a clear pitcher. In front of the blender are several attachments: a grater, a slicer, and a shredder. The Bosch logo is visible on the front of the food processor's base.

**Spalva: juoda**

## Nerūdijančio pieno daugiafunkcis peilis

**Kapokle su MultiLevel6 peiliu greitai ir preciziškai  
susmulkinsite žoleles, riešutus, svogūną ar česnaką  
Pjaustymo (storas ir plonas), tarkavimo (stambus ir  
smulkus) diskai, plastikinis tešlos minkymo diskas  
Plakimo diskas grietinelei ir kiaušinio baltymams plakti,  
visos plastikinės detalės, besiliečiančios su maisto  
produktais yra be BPA**

**Veikia tik tada, kai indas bei dangtelis teisingai uždėti, guminės kojelės**

## Integruotas priedų laikymo skyrius

## Galima plauti indaplovėje

## Garantija 2 metai