



ELECTROLUX ECFB03 Anglies filtras

Tinka modeliams:

DPB2621S, DPB3631S, LFP216S, ZHP60260SA, ZHP60260WA,
LFP316S, LFP315S,
LFP216W, ZHP60350SA, KHP60260SA, DPB3931S, JDF603E9,
JDF602E9, PDP6020E,
DGB1522S, ZHG51251G, ZHG71351G, LFG225S, BHP62220XA,
ZHG51351G, LFG325S,
LFG327S, LFG227S, LFP316AB, LFP316AW, EFP126X, EFP129X,
BHG17320XA,
BHG97320XA, BHG67320XA, LFP316AS, LFP316FB, LFP316FW,
ZFP16S, FHP60350SA,
ZFP216W, LFP326AS, LFP226S, LFP326S, FFG325S, DPB3622S,
LFP326W, ZFG215S,
LFP326AB, LFG337S, DPB3632S, ZFG317S, DGB3523S, LFP325S,
LFG235S, LFG335S,
ZFG315S, LFP326FB, ZFP216S, FFP426X, DPB3932S, ZFP316S,
LFP326FW, KHP62350SA,
JDF604E3, PDP6040E, LFG245S